

How to Inflate Your Kayak

1. Roll out your kayak onto a flat surface.
2. Attach the pump hose to the T-Handle in the inflate position (marked as “OUT”). Make sure the “Action Lever” on the pump is switched to “Double Action”.
3. Starting with Main Chamber 1, remove the cap from the valve and check to see if the stem in the center of the valve is up or down. The stem of this valve must be in the UP (inflate) position to inflate the kayak. If the valve is not up, use your finger to push in and turn the stem counterclockwise. It will spring up into the inflate position.
4. Attach the pump to the valve and inflate until the kayak takes shape and starts to become firm.
5. Switch the pump’s “Action Level” to “Single Action” and continue to inflate to 10-12 psi maximum. Make sure that you do not exceed the maximum psi.
6. Once you are done inflating Main Chamber 1, disconnect the pump hose from the valve and close the valve cap. Lock the valve cap into place by turning clockwise.
7. Move to Main Chamber 2 and repeat steps 3-6.
8. When fully inflated, you’ll notice a dimple on the underside of the kayak, opposite the valve. This is normal.
9. Place the inflatable foot brace perpendicular to the length of the kayak at the front edge of the cockpit and tuck the edges under the cockpit arm. Adjust to desired position, then inflate until firm (3 psi MAX) to wedge it into place.
10. Turn the kayak over and attach the removable fin by sliding it into the fin base. Secure it with the tethered locking tab by inserting it into the corresponding notch in the fin base. Attach seats.

Need help? Give us a call
403-762-4754



How to Deflate Your Kayak

1. Remove the caps from both main chambers. Push valve stems inward and rotate to the deflate position.
2. Remove fin and seats.
3. Once the chambers are deflated you can use your pump to vacuum out any additional air for improved folding.

How to Fold Your Kayak

1. Completely deflate all air chambers and remove the seats and fin.
2. Starting at one end of the kayak, fold the end over. Take care not to put too much pressure on the nose cap when folding as to reduce the risk of deforming it.
3. Roll up the kayak in even sections.
4. Once you reach the other end of the kayak, fold the end over similar to Step 2 and finish rolling up the kayak.
5. Secure with provided strap. Place into duffel bag.

Need help? Give us a call
403-762-4754